

Evolve External Bracket at each end of panel

Glass Width	External Bracket Clearance			Post Width	OC Post Spacing		Between Post Spacing (Face-to-Face)	
	Minimum Airspace		Maximum Airspace		Minimum	Maximum	Minimum	Maximum
12.25	1.5		3.875	3	18.25	23	15.25	20
18.25	1.5		3.875	3	24.25	29	21.25	26
24.25	1.5		3.875	3	30.25	35	27.25	32
31.25	1.5		3.875	3	37.25	42	34.25	39
36.25	1.5		3.875	3	42.25	47	39.25	44
41.25	1.5		3.875	3	47.25	52	44.25	49
46.25	1.5		3.875	3	52.25	57	49.25	54
51.25	1.5		3.875	3	57.25	62	54.25	59
56.25	1.5		3.875	3	62.25	67	59.25	64
61.25	1.5		3.875	3	67.25	72	64.25	69

**Evolve External Bracket at one end of panel
Evolve Angle Bracket at other end of panel**

Glass Width	External	Angle	External	Post Width	OC Post Spacing		Between Post Spacing (Face-to-Face)	
	Minimum Airspace	Minimum Airspace	Maximum Airspace		Minimum	Maximum	Minimum	Maximum
12.25	1.5	3.5	3.875	3	20.25	23	17.25	20
18.25	1.5	3.5	3.875	3	26.25	29	23.25	26
24.25	1.5	3.5	3.875	3	32.25	35	29.25	32
31.25	1.5	3.5	3.875	3	39.25	42	36.25	39
36.25	1.5	3.5	3.875	3	44.25	47	41.25	44
41.25	1.5	3.5	3.875	3	49.25	52	46.25	49
46.25	1.5	3.5	3.875	3	54.25	57	51.25	54
51.25	1.5	3.5	3.875	3	59.25	62	56.25	59
56.25	1.5	3.5	3.875	3	64.25	67	61.25	64
61.25	1.5	3.5	3.875	3	69.25	72	66.25	69

Evolve Angle Bracket at each end of panel

Glass Width	Angle Bracket Clearance			Post Width	OC Post Spacing		Between Post Spacing	
	Minimum Airspace		Maximum Airspace		Minimum	Maximum	Minimum	Maximum
12.25	3.5		3.875	3	22.25	23	19.25	20
18.25	3.5		3.875	3	28.25	29	25.25	26
24.25	3.5		3.875	3	34.25	35	31.25	32
31.25	3.5		3.875	3	41.25	42	38.25	39
36.25	3.5		3.875	3	46.25	47	43.25	44
41.25	3.5		3.875	3	51.25	52	48.25	49
46.25	3.5		3.875	3	56.25	57	53.25	54
51.25	3.5		3.875	3	61.25	62	58.25	59
56.25	3.5		3.875	3	66.25	67	63.25	64
61.25	3.5		3.875	3	71.25	72	68.25	69